

## ◆ HOW TO SET THE MONTHLY CALENDAR

Some models come with a calendar function which uses an inner ring or bezel on the exterior of the case to indicate the date.

The monthly calendar can be used by turning the crown to set the rotating ring inside the watchcase and aligning it with the day of the week that is printed on the dial.

Turn the crown to align the first day of the month to the appropriate day of the week.

- \* Note that when setting the first day of the month, if the days at the end of the month (31st, etc.) are aligned with the section that does not have the days of the week printed on the dial (3 - 4 o'clock side), days of the week will not be indicated at the end of the month.



- \* The position of the inner ring crown and details of the date indicator may vary depending on the model.